

xumo
xfinity

Input

More

Mute

Navigation
OK selection


Back

Home

Voice control


Add

Pairing your Voice Remote




1

Make sure the front of the **TV Box** is not obstructed.




2

Your **TV** and **TV Box** both need to be on, with the TV set to the correct input.



3

Remove **pull tab**. 2AAA batteries are pre-installed.



4

Point the Remote at the TV Box and follow the **onscreen instructions**.

Voice commands

After setup, try these commands while you **hold** the voice button.

“What can I say?”


“Remote settings”

“Free Movies”

Need help?
xfinity.com/chat

Learn more about FCC information at
xfinity.com/xr-remote-fcc-compliance-notice

Explore accessibility features
xfinity.com/accessibility



xumo
xfinity

Input

Más

Silenciar

Navegación
Seleccionar OK


Atrás

Inicio

Control por voz


Agregar

Enlaza tu nuevo Control Remoto por voz




1

Asegúrate de que la parte frontal de la **caja de TV** no esté obstruida.




2

Ambos tu **TV** y tu **caja de TV** necesitan estar encendidas, con el televisor en la entrada correcta.



3

Quita la **pestaña trasera**. Las baterías 2AA ya están instaladas.



4

Apunta el control remoto hacia la caja de TV y sigue las **instrucciones en pantalla**.

Comandos de voz

Después de terminar la configuración, prueba diciendo estos comandos mientras **mantienes apretado** el botón de voz.

“Muéstrame deportes”

“Configuración”

“Películas gratis”

¿Necesitas ayuda?
es.xfinity.com/chat

Más información sobre FCC en
es.xfinity.com/xr-remote-fcc-compliance-notice

Descubre funciones de accesibilidad
es.xfinity.com/accessibility

308914