

Get started

xfinity



1 Make sure the front of the **TV Box** is not obstructed.

2 Your **TV** and **TV Box** need to be on, with the TV set to the correct input.



3 Remove **pull tab**.
2AA batteries are pre-installed.

4 Point the Remote at the TV Box, press the **Voice button** and follow the **onscreen instructions**.

Accessibility

Voice control

Home

Mute

Navigation
OK selection

PG PG **Page up / down**

Need help? **xfinity.com/chat**


Learn more about FCC information at
xfinity.com/xr-remote-fcc-compliance-notice

Explore accessibility features
xfinity.com/support/accessibility

Antimicrobial additives protect this remote from the growth of bacteria.


Empieza aquí

xfinity



1 Asegúrate de que la parte frontal de la **Caja de TV** no esté obstruida.

2 Ambos tu **TV** y tu **caja de TV** necesitan estar encendidas, con el televisor en la entrada correcta.



3 Quita la **pestaña trasera**. Las baterías 2AA ya están instaladas.

4 Apunta el control remoto hacia la caja de TV, presiona el **botón de voz** y sigue las **instrucciones en pantalla**.

Accesibilidad

Control de voz

Inicio

Silenciar

Navegación
Seleccionar OK

PG
PG

Página arriba / abajo

¿Necesitas ayuda? **es.xfinity.com/chat**

Más información sobre FCC en
es.xfinity.com/xr-remote-fcc-compliance-notice

Explora la accesibilidad en
es.xfinity.com/support/accessibility

Aditivos antimicrobianos protegen este control remoto del crecimiento de bacterias.